



Overview of ISRU Activities at KSC, FIT, and UT-PR

Presented by
Clyde Parrish

Acknowledgement

Dale Lueck, Rolando Roque, Paul Jennings, Jon Whitlow,
Jan Surma, Eddie Santiago, and Lilly Fitzpatrick

July 2003

Current Projects At KSC

- Gas Separation Processes
 - Low Temperature Membranes
 - Immobilized Liquid Membranes
 - Microencapsulated Liquid Membranes
- Oxygen Production Technologies
 - RWGS
 - Ionic Liquids
 - Molten Salts






Gases Separation Processes


- Separation Methods
 - Hollow-Fiber Membranes
 - Immobilized Liquid Membranes
 - High temperature Membranes (300 to 500 C)
 - Microencapsulated Liquid Membranes
- Applications
 - Buffer Gases for Mars
 - Water Removal from RWGS Process
 - CO₂ Removal for EVA and Spacecraft Applications
 - Regenerative Live Support
- Technical Challenges

Low-Temperature Membrane Test Bed






Capture Design for Buffer Gas at - 44° C





Membrane System Design for Buffer Gas at - 44° C




Stream	1	2	3	4	5	6
% CO ₂	30	27.62	56.53	8.06	0.06	20.04
% Ar	26	26.9	15.84	34.37	37.72	29.37
% N ₂	44	45.48	27.61	57.56	62.22	50.59
Liter/hr	12.77	16.78	6.77	10.01	6	4.01
mm Hg	780	780	6	780	780	6


Sample Cell for Membrane Sheet




Immobilized Liquid Membranes



Preparation



Structure



Sample Cell


Immobilized liquid membrane preparation, structure, and sample cell



Ionic Liquids



- What are they?
 - Low melting ionic salts. By using large anions and cations, a low temperature melt with conductivity similar to molten salts can be obtained.
 - Examples include pyridinium and imidazolium cations with anions such as PF_6^- , BF_4^- , and many others.
- Desirable Properties
 - Low temperature (177 – 573K).
 - High conductivity (low $I \cdot R$ losses).
 - Wide electrochemical window.
 - Non-volatile.
 - Miscible with or high solubility for CO_2 .

Microencapsulated Liquid Membrane



A microcapsule, group of microcapsules on a porous membrane,
and vapors of a monomer that permeates the capsules



Ceramic Membrane Cell



Complex ceramic membranes for hydrogen Separations

Oxygen Production Technologies

- RWGS
- Ionic Liquids
- Molten Salts




RWGS Cyclic Processes with Water Electrolysis

- Reverse Water Gas Shift Reaction (RWGS)
- Desiccant Electrolysis and RWGS
- Carbon Monoxide Removal






RWGS Process Flow Diagram



Cascade RWGS Reactor





Base Case for Staged Simulations


	Stage1	Stage2	Stage3	Stage4	Stage5	Stage6
Reactor Temperature(C)	400	400	400	400	400	400
Condenser Temperature(C)	5	5	5	5	5	5
Reactor Pressure (psia)	80	64	48	32	20	12
Membrane Delta P (psia)	16	16	16	12	8	8
Permeate Delta P (psia)	0.15	0.21	0.36	0.70	1.31	3.28
Permeate CO ₂ Sweep (slpm)	3	3	3	3	3	3
H ₂ Reactor Feed (slpm)	4	2.50	1.38	0.60	0.16	0.01
CO Reactor Feed (slpm)	0.000	0.147	0.101	0.053	0.012	0.002
H ₂ in Reject (slpm)	0.00006	0.00007	0.00013	0.00358	0.00212	0.00008
CO in Reject (slpm)	1.35638	1.15943	0.83380	0.47623	0.15234	0.01543
Overall H ₂ Conversion	37.44	65.28	84.92	95.90	99.50	99.84

Molten Carbonate Electrolysis of CO₂





Anode Reaction




Cathode Reaction



Overall Reaction



Ceramic MC Cell–Initial Response (-1.5V bias, 550°C)





Ionic Liquids for Carbon Dioxide Electrolysis

- Ionic liquids allow lower processing temperatures
- Organic polymers can be used for gaskets and stainless steel for cells
- Wide electrochemical window
- Good mobility of ionic species
- Low temperature Reactions
 - Anode Reaction
$$\text{CO}_2 + 4 \text{e}^- \rightarrow \text{C} + 2 \text{O}^{2-}$$
 - Cathode Reaction
$$2 \text{O}^{2-} \rightarrow \text{O}_2 + 4 \text{e}^-$$
 - Overall Reaction
$$\text{CO}_2 \rightarrow \text{C} + \text{O}_2$$
 - Carbon removal from ionic liquid